


Sliding Gate Opener

User's Manual




- ◆ Thank you for purchasing the sliding gate opener.
- ◆ Please read and follow all warnings, precautions and instructions before installation and using.
- ◆ Periodic checks of the opener are required to ensure safe operation.
- ◆ Keep the manual for future reference

Contents

1.General Safety	1
2.Product Description	2
2.1 Part List	2
2.2 Optional Accessories Parts List	3
2.3 Technical Specifications & Features	3
3.Installation Overview	4
3.1 Gate Opening Default Setting Information	(4)
3.2 Install the Motor	(4)
4.Connection of the Power Supply	7
5.Connection of the Control Board	7
6.Control Board Function Description	10
7.Digital Display Setting	11
8.How to Program or Erase the Remote	12
9.How to Use the Remote to Operate Your Gate Opener	13
10.Smart Control Mode by Adding a Smart Module(Optional)	13
10.1 How to Program and Operate the 2.4G Transmitter	(13)
10.2 How to Add and Operate the Bluetooth Device	(14)
11.Maintenance	14
12.Trouble Shooting	14

CHECK YOUR GATE

Before installation, please make sure that the gate itself can be opened and closed smoothly & freely BY HAND WITHOUT THE GATE OPENER.



1. General Safety




WARNING! An incorrect installation or improper use of the product can cause damage to persons, animals or properties, should always request the assistance of qualified personnel.


- This product was exclusively designed and manufactured for the use specified in the present documentation. Any other use not specified in this documentation could damage the product and be dangerous.
- The factory declines all responsibility for any consequences resulting from improper use of the product, or use which is different from that expected and specified in the present documentation.
- Do not install the product in explosive atmosphere or where there is any danger of flooding.
- To AVOID damaging gas, power, or other underground utility lines, contact underground utility locating companies BEFORE digging.
- Disconnect the electrical power supply before carrying out any work on the installation or maintenance.
- Please ensure that the using power voltage matches with the supply voltage of gate opener (AC220V±10% 50Hz).
- To ensure safety, before installing the motor, all potential hazards and exposed pinch points of the gate must be eliminated or guarded prior, and make sure Gate End Stop and a Gate Stopper mounted at each end of the rail to prevent the gate travelling off the track.
- Never mount any device that operates the gate motor where the user can reach over, under, around or through the gate to operate the controls. These must be placed at least 1.8m from any moving part of the moving gate.
- Keep remote control and other control devices out of children's reach, in order to avoid unintentional activation.
- If required, install infrared photocells (sold separately) to detect obstructions and prevent injury or damage.
- Instruct all users about the control systems provided and the manual opening operation in case of emergency.
- Anything which is not expressly provided for in these instructions is not allowed and will void warranty.
- Only use original parts for any maintenance or repair operation. We decline all responsibility with respect to the automation safety and correct operation when other supplier's components are used.

2. Product Description


The PYM-H2207 motor was designed as a device for moving sliding gates. The way of the gear works prevents the gate from moving when the motor is turned off, so there is no need to use an electric lock. Avoid a power failure, user can use the override key to unlock the clutch to manual open or close the gate.



2.1 Part list




Motorx1




RHS/LHS Limit Switch
Striker Platex2



Motor to mounting
plate screwsx4




Motor Base Platex1




Adjust Boltsx4



Striker Plate
Fixing Boltsx4




Remotex2




Override keysx2


2.2 Optional Accessories Parts List (Available at Giant Store)




Gear Rack



Photocell Sensor




Flash Lamp




TKM-01




Wifi controller



Remote Control



ST-01/02/03



Smartphone Remote Control with Camera

2.3 Technical Specifications

Power supply	Three-phase motor AC 220V±10%
Maximum load	2500KGS
Rated power	250W
Rated speed	1400RPM
Output Speed	50Rr/min±10%
Running speed	12m/min
Output torque	62 N.m
Output gear module	M=4
Output gear number	Z=16
Remote control distance	≤50 meter
Working humidity	≤85%
Maximum pull	2300N
Noise	≤55dB
Protection Class	B
Working temperature of motor	-20°C ~ +55°C
Net weight	12KG
Packing	In a standard carton


Features of sliding gate opener

- Soft start and slow stop.
- Automatic closing function adjustable from 1 to 99 seconds.
- Thermal protection against engine overheating.
- Anti-pinch protection in case of meeting an obstacle.
- Signaling the current operating status of the machine on the display.
- Ability to support up to 120pcs remote controls.
- Possibility to assign one of 8 functions to 4 buttons on the remote control.
- Possibility to connect external buttons and control devices (e.g.push button, wifi controller, radio receiver etc).
- Possibility of partial opening of the gate, without the need to perform the full scope of work.
- Manual release of the gate in the event of a lack of 220V mains voltage.
- Add smart module for 2.4G bluetooth control (optional).


3. Installation Overview

3.1 Gate Opening Default Setting Information

The gate motor will open the gate to the right-hand side as its default setting (Refer to diagram 2).



If your gate needs to open from the other direction (to the left, refer to diagram 3) your motor needs to be mounted on the left-hand side as shown, you will need to switch 2 wires of motor (diagram 10) at random.



3.2 Install the Motor

• Installation of motor base plate

1. Depending on the installation size of the motor and mounting height of racks, after determine the installation position of the motor base plate, first let the bolt embedded or use expansion bolt to make base plate fixed on watering good cement foundation. See diagram 4.




Diagram 4


2. If gear rack has been installed on door, motor can be fixed on it, use a allen key rotation to clutch "off" position, after motor gear and gear rack match well to determine position of base plate, then remove motor and fix base plate.

• Installation of gate opener


1. Put gate opener on base plate, use a random matching hexagon screw make the motor fixed on the base plate.
2. Unscrew the screws fixed the motors cover, remove motor cover. According electrical wiring diagram, connected power cord, after adjust in good position, then install cover and use screws to fixed it.

• Preparing for gear racks installation

Using the supplied override key unlock the clutch and pull out manual override lever (see diagram 5) then manually close the gate.



Insert Key, rotate 90 degrees
Diagram 5



Releasing arm in torsion, wriggle 90 degrees
gate operator will be in releasing state

• Install the gear rack on the gate

Each piece of rack will interlock into the next piece (see diagram 6).

The best method for installation is to first close the gate using the manual override, sit the first piece on the gear of the motor (make sure it is 100% level first) then fix directly to the gate in the centre of the fixing hole of the rack. Now loosen the fixing and adjust the spacing between the motor gear and the gear rack (allow 2-3mm gap)

Re-tighten and fix the next remaining holes on the rack.

Move the gate manually forward and backward along the installed rack to ensure that the gap between the rack and the gear is consistent throughout.

Clip in the next piece of rack into the first (make sure it is 100% level first) then fix directly to the gate in the centre of the fixing hole of the rack.

Again move the gate manually forward and backward along the installed racks to ensure that the gap between the rack and the gear is consistent throughout. Repeat the above method to complete the racks installation and always be sure to move the gate manually forward and backward every time you install another piece of the rack.






Diagram 6

The striker plates must be installed now to set the open and close positions for the motors operation. They are fixed onto the gear rack and should strike the limit switch spring on the motor to set the operating parameter (see diagram 7).

Using the manual override open the gate to the desired open position and install the open striker then close the gate to the desired position and install the closed striker (small adjustment afterwards may be necessary to achieve the best results when the motor is powered later).



• Typical installation layout:




- | | | |
|-------------------------|------------------------------|-----------------------|
| ① Gate catch(optional) | ② Photocell sensor(optional) | ③ Gate motor |
| ④ Gate roller(optional) | ⑤ Flash lamp(optional) | ⑥ Gear rack(optional) |
| ⑦ Limit plate | ⑧ Gate stopper(optional) | |

4. Connection of the Power Supply and Control board



WARNING! NEVER connect the gate opener to the power outlet before all the installations have been done.

Only use the AC electricity as the power source



5. Connection of the Control Board




Diagram 9

The following functions refer to the picture control board layout.

- 1&2. Power: used for connecting with AC 220V power supply.
- 3&4. Lamp: used for connecting with flashing light, output voltage is AC 220V.
- 5&6&7. Motor: used for connecting with sliding gate motor's wire.
- 8 VCC: DC 12V output used for connecting with external devices, max 100mA.
- 9 COM: used for connecting with COM terminal or GND.
- 10 IR: used for connecting with the photocell sensor.
- 11 Start: It is a single button control mode switch for controlling the gate by "open - stop - close - stop - open" cyclically.
- 12.COM: used for connecting with COM terminal or GND.
- 13 Close: used for connecting with any external devices that will operate to close the gate.
- 14.Open: used for connecting with any external devices that will operate to open the gate.
- 15.ANT: antenna connection.
- 16.LEARN: It is for programming/removing the remote control.
- 17.DEC/SMART: It is for figure decreasing of setting the data and add intelligent device.
- 18.FUN: It is for storing data.
- 19.INC/START: It is for figure increasing of setting the data and setting the single button control mode.

Programming

D1: The photocell sensors output signal instructions

LED ON: Photocell sensors detection, if there have obstacle when closed the door, the motor will stop working. LED OFF: Photocell sensors detection, there is no obstacle.

D2: LED ON: Warning light on flashing.

D3: Limit switch of closing the door.

LED ON: The door is not completely closed

LED OFF: The door is completely closed

D4: Limit switch of opening the door.

LED ON: The door is completely opened

LED OFF: The door is not completely opened

D5: Indicate for operation of smart module

D6: LED ON: the board with power on

D7: Indicate for learning/Delete remote control

D8: LED ON: Gate on closing

D9: LED ON: Gate on opening

• Connect with motor





Diagram 10


Terminal (5) , (6) and (7) is for connecting with the motor.

- Connect with flash lamp



Terminal ③ and ④ is for connecting with the flash lamp .

- Connect with photocell sensor




Connect terminal ⑫ with the "COM " of photocell RX.
 Connect terminal ⑩ with the "OUT " of photocell RX.
 Connect terminal ⑧ with the "+" of photocell RX and TX.
 Connect terminal ⑨ with the "-" of photocell RX and TX.

Please note: the sliding gate control board is factory set to connect NO model of photocell, So please keep the jumper on the NO, as picture DIAGRAM 11 show!


- Connect with Start terminal for "open-stop-close-stop-open" cycle controlling mode

Start terminal is used for connecting with some external devices , such push button, wired keypad, receiver etc.
 Control gate by " open-stop-close-stop-open " mode



Terminal ⑧ and ⑨ is for supplying the power to the push button.
 Terminal ⑪ and ⑫ is for connecting with the push button.

- Connect with open/close gate device



Open gate device:

Terminal ⑧ and ⑨ is for supplying the power to the push button.

Terminal ⑫ and ⑭ is for connecting with the device.

Close gate device:

Terminal ⑧ and ⑨ is for supplying the power to the push button.

Terminal ⑫ and ⑬ is for connecting with the device.

6. Control board function description

Item	Description
Power on	After the control board powered on, the buzzer will sound, and the digital display will show model number and version, and the status 15 indicator LED lit up.
Resistance functions	The resistance function can achieve an anti-smashing car. While the gate motor is opening, it meets obstruction and will stop. If the gate motor is closing and meets the obstruction, the gate will be reopened. The motor's low-speed and high-speed running resistance sensitivity can be set through the digital display menu P0 and P1.
Limit function	While the gate moves to the open or close position, the motor will auto-stop running. The limit mode can be set through the digital display menu P7, has NC and NO mode for optional.
Infrared resistance function	While the gate is closing, if the infrared is triggered, the gate will rebound to open. When the gate is opening fully, after 3s, the gate will be auto-closed.
Auto close	The auto-closing function is only activated after the open limit switch is enabled. When auto-close start to countdown, the STATE LED will flash one time each second. Auto close time can be set through the digital display menu P6.
Pedestrian mode PED	The remote 4th button can trigger the PED mode. When user trigger the PED mode, the gate will be auto open; At the moment, if user also activate the auto close function, then the motor will enter auto close countdown and close gate after time end. While user activate the PED mode, the gate open time and auto close count down time can set through the digital display menu P4 and P5.

Lamp function	When the gate is moving, the lamp will light on, when the gate is stop moving, the lamp will turn off. When the gate is on the auto-close countdown state, the lamp also will light on.
Motor protection	As soon as the motor runs continuously for more than the 90s, the motor will automatically stop working to protect the motor. When the control board detects that the temperature of the motor drive module exceeds the threshold, it will immediately cut off the power supply of the motor, the digital display will show "OH", and the system is in an overheating protection state, and the motor cannot be controlled at this time. When the temperature drops to a certain level, the system will release the overheating protection state.
Smart module (optional)	<ol style="list-style-type: none"> 1. Program the 2.4G transmitter: Short press the DEC/Smart button, the buzzer will sound once, smart indicator LED will light on, enter the programming mode. Transmit the 2.4G signal, if the indicator LED flash twice and keep lighting on, which means the programming is successful. Otherwise, after 8s will exit the programming mode automatically. 2. 2.4G control mode: while the mode received the 2.4G signal, it will open the gate once 3. Add the bluetooth device: Open the XHouse IOT app, enter the add device mode, and choose the bluetooth device. Choose the correct bluetooth device, press the add button. (The bluetooth device mode number is XHOUSE_092BLE_XXXXXX, XXXXXX is its serial number). 4. Bluetooth device control mode: On the app, there has three buttons, including open, close and stop. 5. Initialize the bluetooth device: Hold press the 2.4G button about 5s, while you hear the buzzer sound two beep, release the button, the operation is complete. 6. Factory reset the bluetooth device: Hold press the 2.4G button about 10s, while you hear the buzzer sound with a long beep, release the button. After that, the module will erase all the 2.4G transmitter and initialize the bluetooth device.

7. Digital Display Setting

- ◆ Press and hold the [FUN] button for 3 seconds, and the digital display will indicate "P0", then release the button, now the menu can be set to [INC/START] and [DEC/SMART] for increasing and decreasing numbers or values.
- ◆ After adjusting the value, press the [FUN] button to store the data, and the buzzer will beep one time to show the store successfully.
- ◆ After the menu setting is finished, press the [LEARN] button to exit the menu setting and close the display.

Item	Function description	Value	Factory set	Explanation
P0	Low speed resistance sensitivity	0-20 level	12 level	The larger the value, the higher the resistance and the harder it is to meet resistance.
P1	High speed resistance sensitivity	0-20 level	10 level	
P2	Low speed adjustment	0-12 level	5 levels	The larger the value, the faster the slow speed.
P3	High speed adjustment	0-12 level	0	The larger the value, the faster the high speed.
P4	High speed running time	0-60s	12s	0: Turn off high speed
P5	Auto-open gate time for PED mode	0-20s	6s	0: PED mode auto-open gate function off
P6	Auto-close gate time for PED mode	0-99s	10s	0: PED mode auto-close gate function off
P7	Auto-close gate time	0-99s	0	0: Auto-close function off
P8	Limit switch mode optional	0-1	0	0: NC mode 1: NO mode
P9	RF remote button control mode	0-1	0	0: Three-buttons mode 1: Single button mode
PA	Reduce Speed For High-Speed Mode	0-5 level	0	The larger the value, the stronger the high-speed braking force (the shorter the sliding distance when stopping)
Po	Reset to factory setting	0-10	0	5: Reset to factory setting

NOTE:

When gate motor is working, if trigger pedestrian mode then gate motor will stop at once. After 6s of trigger pedestrian mode to open gate The auto open time can set from 0-20s, factory setting is 6s. neither now enter the auto close time count down or stop, if you trigger pedestrian mode again, then gate will auto close at once.

Control board digital display information show:

1. When the gate is start to open, the digital display will show 1S "OP"
2. When the gate is start to close, the digital display will show 1S "CL"
3. After the gate stop moving, the digital display will show 1S "-"
4. When the gate moves to the full open limit, the digital display will show 1S "LO"
5. When the gate moves to the full close limit, the digital display will show 1S "LC"
6. When the motor reaches max working time, the digital display will show 1S "EC"
7. After the motor trigger the overload protection, the digital display will show 1S "OU"
8. After the photocell is activated, the digital display will show 1S "PH"
9. After the PED mode is activated, the digital display will show 1S "PD"
10. After the motor protection is activated, the digital display will show 1S "OH"

8. How to Program or Erase the Remote

The remote **MUST** be programed to the opener **BEFORE OPERATING**. Please follow the steps to program the remote.

Activate the opener only when gate is in full view, free of obstruction and properly adjusted. No one should enter or leave gate area while gate is in motion. **DO NOT ALLOW CHILDREN** to operate push button or remote. **DO NOT ALLOW CHILDREN TO PLAY NEAR THE GATE.**